
IP44. DE outside lighting[®]

piek

instructions for use

- 1. Unscrew light housing off the ground spike.
- 2. Insert light bulb.
- 3. Screw light housing on and pay attention to density.
- 4. Attach ground spike in the ground and look after a secure stand.
- 5. Conduct electrical junction by safety plug.
- 6. Fix mains cable between round blanks in the ground spike.
- 7. Power outlets have to correspond to the essential protection class.



light technology:

tungsten halogen lamp QPAR51 no cool beam 50W/GZ10



technical information:

operating voltage 230V / 50Hz



protection class



safety class 1



Luminaire is suitable for mounting on normal inflammable fixing surfaces.



conformity mark

relamping and maintenance:

Disconnect the electrical installation.

Change lamp. Check the gaskets and if necessary clean or replace it.

Take notice of care-instructions when cleaning the luminaire. For cleaning do not use a high pressure cleaner.

care

Regularly clean luminaire from dirt and deposits.

See service documents:

Head: Care of anodized aluminium.

Pole: Care of stainless steel rustless.

safety:

We point out that the electric connection of light fixtures has to be done by a certified installer.

We assume no accountability for damages which are a result of non-appropriate mounting or application of the luminaire.

Modifications on the luminaire will result in loss of warranty.

The safety plug signals the changeable location of the luminaire. Please note, that a fixed installation and/or a connection with an earth-joint is not provided.

Attention: Please note that some parts of this luminaire can produce temperatures higher than 90°C when it is in operation. To prevent burns, please avoid any contact!

Please keep the instructions with the service documents!

welcome@IP44.de . www.IP44.de 4.01 03/16